




RL8105

LEG EXTENSION/LEG CURL OWNER'S MANUAL

21J

CAUTION! Read all precautions and instructions in this manual
before using this equipment.

Table Of Contents

CAUTION!

Read all precautions and instructions in this manual before using this equipment.

Important Safety Instructions-----	3
Instructions-----	5
Exploded View and Parts List-----	6
Measurement Guide-----	12
Assembly Instructions-----	13
Assembly-----	14
Adjust Instructions-----	19
Maintenance Schedule-----	20
General Maintenance Information-----	21
Weight Training Tips-----	22

Important Safety Instructions

Before beginning any fitness program, you should obtain a complete physical examination from your physician. When using exercise equipment, basic precautions should always be taken, including the following:

1. Read all instructions before using the equipment.
These instructions are written to ensure your safety and to protect the unit.
2. Use the equipment only for its intended purpose as described in this guide.
Do not use accessory attachments that are not recommended by the manufacturer: such attachments might cause injuries.
3. The product should only be used on a level surface and is with 0.5 meters space around the product.
Do not use the equipment outdoors.
4. Do not allow children on or near the equipment. And children are not allowed to use this equipment.
Teenagers should use this equipment with adult supervision.
5. Do not overexert yourself or work to exhaustion.
Do not attempt to lift more weight than you can control safely.
If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.
6. This equipment is not used as medical apparatus and instruments.
7. Never operate the unit when it has been dropped or damaged.
Never drop or insert anything into any opening in the equipment.
Always check the unit and its cables before each use. Make sure that all fasteners and cables are secure and in good working condition.
Frayed or worn cables can be dangerous and may cause injury. Periodically check these cables for any indication of wear.
Keep hands, limbs, loose clothing and long hair well out of the way of moving parts.
8. Be careful when getting on or off the equipment.
9. Wear proper exercise clothing and shoes for your workout, no loose clothing.


Important Safety Instructions

Personal Safety During Assembly

Read each step in the assembly instructions and follow the steps in sequence. Do not skip ahead. If you skip ahead, you may learn later that you have to disassemble components and that you may have damaged the equipment.

Assemble and operate the equipment on a solid, level surface. Locate the unit a few feet from walls or furniture to provide easy access. The equipment is designed for your enjoyment. By following these precautions and using common sense, you will have many safe and pleasurable hours of healthful exercise with the equipment.

Training Area and Free Area



Specifications

Class: S

Maximum User Weight: 150kg/ 330lbs

Product Total Surface: 850*1185mm


Product Total Mass:

Instructions


Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only our replacement part when servicing. Failure to do so will void your warranty and could result in personal injury.

The equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.


Tools Required




Ratchet Wrench and Socket




Adjustable Wrench



Rubber Mallet



Hex Key Wrench Set



Phillips Screwdriver


Exploded View and Parts List

Overall

Item No.	Grade No.	Part No.	Description	QTY
1	1	RL810501ASSY	Seat Pad Frame ASSY	1
2	2	RL810502ASSY	Back Pad Frame ASSY	1
3	3	RL810503ASSY	Connection Frame ASSY	1
4	4	RL810504ASSY	Swing Frame ASSY	1
5	5	RL810505ASSY	FOAM Frame ASSY	1
6	6	RL81053100	Decorative Boards	1
7	7	RL81013100	Decorative Sleeve	1
8	8	RL81014000	Cup Holder	1
9	9	ST56-390SASSY	Hydro-Cylinder ASSY	1
10	10	PL90197600	Leather Wrapped Round FOAM	2
11	11	RL81055100	Seat Pad	1
12	12	HD24006300	Bush of Rolling Pad $\Phi 76.2 \times \Phi 39.5 \times 30.5$	4
13	13	RL81013800	Fixed Button	4
14	14	RL81052200	Aluminium Cap $\Phi 72 \times 14.4$	1
15	15	RL81052300	Locking Ring $\Phi 45 \times \Phi 26 \times R32.5 \times 10$	1
16	16	IN-D10132300	Aluminium Cap $\Phi 43 \times \Phi 10.5 \times 8$	1
17	17	IT80011800DS	Adjustable Ring $\Phi 30 \times 2 \times 3$	2
18	18	IE950716500	Aluminium Cap $\Phi 60 \times 11.6$	3
19	19	GB70BTM10*20DN18NL	Socket Head Cap Screw M10*20	1
20	20	PNLM10*40N19	Button Head Cap Screw M10*40	1
21	21	GB70BTM10*105DN18	Socket Head Cap Screw M10*105	1
22	22	GB70BTM10*75DN18	Socket Head Cap Screw M10*75	4
23	23	GB70BTM10*30DN18	Socket Head Cap Screw M10*30	7
24	24	CNLM10*30*30DN20	Flat Head Cap Screw M10*30	4
25	25	CNLM10*40N19NL	Flat Head Cap Screw M10*40	1
26	26	GB9510DN2	Flat Washer $\Phi 11 \times \Phi 20 \times 2$	11
27	27	GB9310N19	Spring Washer $\Phi 10$	6
28	28	NM10DN2	Nylon Lock Nut M10	3
29	29	GB845ST4.2*16N19	Cross Recessed screw ST4.2*16	4
30	30	NBS6DS	Hex Key S=6	1
31	31	LW200BS	Wrench $\Phi 6 \times 117$	1


Exploded View and Parts List

Overall



Exploded View and Parts List


Seat Pad Frame ASSY



Item No.	Grade No.	Part No.	Description	QTY
1	1.1	RL81050100	Seat Pad Frame	1
2	1.2	B4001600	Wheel ASSY	2
3	1.3	B4002200	Adjustment ASSY	2
4	1.4	CWRVL0051800	Aluminum Grip Cap $\Phi 25$	2
5	1.5	V39500	Aluminum Grip Ring $\Phi 25.4$	2
6	1.6	026-01PL0206-12	Grip $\Phi 30 * \Phi 22 * 130$	2
7	1.7	GB819M5*15N19	Cross Recessed screw M5*15	4
8	1.8	YZGB7710-32*3.2N19	Socket Set Screw 10-32UNF*3.2	8

Exploded View and Parts List


Back Pad Frame ASSY




ItemNo.	Grade No.	Part No.	Description	QTY
1	2.1	RL81050200	Back Pad Frame	1
2	2.2	RL81013200	Back Pad Cover	1
3	2.3	RL81013300	Head Pad Cover	1
4	2.4	RL81015200	Back Pad	1
5	2.5	RL81015300	Head Pad	1
6	2.6	GB70BTM10*30DN18	Socket Head Cap Screw M10*30	6

Exploded View and Parts List

Connection Frame ASSY



Swing Frame ASSY




ItemNo.	Grade No.	Part No.	Description	QTY
1	3.1	RL81050300	Connection Frame	1
2	3.2	RL81052200	Aluminium Cap $\Phi 72 \times 14.4$	1
3	3.3	B10009900	Plug $\Phi 50.8$	1
4	3.4	CNLM10*30*30DN20	Flat Head Cap Screw M10*30	1


ItemNo.	Grade No.	Part No.	Description	QTY
1	4.1	RL81050400	Swing Frame	1
2	4.2	M02502000	Bushing $\Phi 38 \times \Phi 25.4 \times 18$	2
3	4.3	GB2766205-2ZC3	Deep Groove Ball Bearing $\Phi 25 \times \Phi 52 \times 15$	2

Exploded View and Parts List

FOAM Tube ASSY




Hydro-Cylinder ASSY



ItemNo.	Grade No.	Part No.	Description	QTY
1	5.1	RL81050500	FOAM Frame	1
2	5.2	IN-D10132300	Aluminium Cap $\Phi 43*\Phi 10.5*8$	1
3	5.3	CNLM10*30*30DN20	Flat Head Cap Screw M10*30	1

ItemNo.	Grade No.	Part No.	Description	QTY
1	9.1	ST56-390S	Hydro-Cylinder	1
2	9.2	RL81013500	Hydro-Cylinder Cover A	1
3	9.3	RL81013600	Hydro-Cylinder Cover B	1
4	9.4	GB845ST4.2*25DS	Cross Recessed screw ST4.2*25	6

Measurement Guide



Diameter of bolt (mm/inch)	M6(1/4")	M8(5/16")	M10(3/8")	M12(1/2")	M16(5/8")
Tightening torque (N.m)	9~12	22~30	45~59	78~104	193~257
Operational methods for adult men	The strength of the wrist	The strength of the wrist and forearm	The strength of the entire arm	The strength of the arm and upper body	with all strength

Assembly Instructions

Assembly of the equipment takes professional installers about 2 hours. If this is the first time you have assembled this type of equipment, plan to spend more time. It is strongly recommended to assemble the equipment by professional installers. You may find it quicker, safer, easier to assemble this equipment with the help of a friend, as some of components may be large, heavy or awkward to handle alone. It is important that you assemble your product in a clean, clear, uncluttered area. This will enable you to move around the product while you are fitting components and reduce the possibility of injury during assembly.

NOTE


As with any assembled part, proper alignment and adjustment is critical. While tightening the fasteners, be sure to leave room for adjustments. Do not fully tighten the fasteners until instructed to do so. Be careful to assemble the components in the sequence presented in this guide.

Assembly

STEP 1

1. Attach the Cup Holder (#8) to the Back Pad Frame ASSY (#2) using:
four ST4.2*16 Cross Recessed screw (#29)
2. Attach the Back Pad Frame ASSY (#2) and Decorative Sleeve (#7) to the Seat Pad Frame ASSY (#1) using:
one M10*105 SHCS (#21)
one Φ 11* Φ 20*2 Flat Washer (#26)
four M10*30 SHCS (#23)
five ϕ 10 Spring Washer (#27)
3. Attach the Connection Frame ASSY (#3) to the Seat Pad Frame ASSY (#1) using:
one Φ 60 Aluminium Cap (#18)
one M10*40 FHCS (#25)
two M10 Nylon Lock Nut (#28)
two M10*75 SHCS (#22)
four Φ 11* Φ 20*2 Flat Washer (#26)

Note: Wrench Tighten Bolts and Nylon Lock Nuts.



Assembly

STEP 2

Attach the Swing Frame ASSY (#4) to the Connection Frame ASSY (#3) using:


one $\Phi 72$ Aluminium Cap (#14)

one $\Phi 45 \times \Phi 26 \times R32.5 \times 10$ Locking Ring (#15)

two $\Phi 30 \times 2 \times 3$ Adjustable Ring (#17)

one M10*30 FHCS (#24)

Note: Wrench Tighten Bolts.




Assembly

STEP 3

1. Attach the FOAM Frame ASSY (#5) to the Swing Frame ASSY (#4) using:
one $\Phi 43$ Aluminium Cap (#16) one M10*20 SHCS (#19)
one M10*30 FHCS (#24)
2. Attach the Hydro-Cylinder ASSY (#9) to the Connection Frame ASSY (#3) and Swing Frame ASSY (#4) using:
one M10*40 BHCS (#20) one M10*30 SHCS (#23)
two $\Phi 11*\Phi 20*2$ Flat Washer (#26) one $\Phi 10$ Spring Washer (#27)
one M10 Nylon Lock Nut (#28)

Note:

1. Wrench Tighten Bolts and Nylon Lock Nuts.
2. Before using the machine, please make sure the Adjustment Knob upwards and tighten the HEX Nut.




Assembly

STEP 4

Attach the Decorative Boards (#6) to the Seat Pad Frame ASSY (#1) using:
four Fixed Button (#13)

Note: Install the fastening.




Assembly

STEP 5

1. Attach the Leather Wrapped Round FOAM (#10) to the FOAM Frame ASSY (#5) using:
four $\Phi 76.2 \times \Phi 39.5 \times 30.5$ Bush of Rolling Pad (#12)
two $\Phi 60$ Aluminium Cap (#18)
two M10*30 FHCS (#24)
2. Attach the Seat Pad (#11) to the Seat Pad Frame ASSY (#1) and Connection Frame ASSY (#3) using:
two M10*75 SHCS (#22)
two M10*30 SHCS (#23)
four $\Phi 11 \times \Phi 20 \times 2$ Flat Washer (#26)


Note: Wrench Tighten Bolts.



Adjust Instructions

Instructions

1. Select an appropriate Lever by Adjusting the Adjustment Knob.
2. Make sure the Adjustment Knob upwards.
3. The moving wheels are of benefit when you adjust the machine's position.



Maintenance Schedule

ROUTINE	COMMERCIAL MAINTENANCE	HOME MAINTENANCE	LATEST DATE ENTRY						
Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack Pins	DAILY	WEEKLY							
Clean; Upholstery	DAILY	WEEKLY							
Inspect; Cables or Belts and their tension	DAILY	WEEKLY							
Inspect; Accessory Bars, and Handles	WEEKLY	3 MONTHS							
Inspect; All Decals	WEEKLY	3 MONTHS							
Inspect; All Nuts and Bolts, Tighten if needed	WEEKLY	3 MONTHS							
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS							
Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	MONTHLY	3 MONTHS							
Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	MONTHLY	3 MONTHS							
Clean and Wax; All Glossy Finishes	6 MONTHS	YEARLY							
Repack with Grease; Linear Bearings	6 MONTHS	YEARLY							
Replace; Cables, Belts and Connecting Parts	YEARLY	3 YEARS							

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.

General Maintenance Information

Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

- * Check all pieces for signs of visible wear or damage.
- * Check springs in snap hooks and pull-pins for proper tension and alignment.
- * If the spring sticks or has lost its rigidity, replace it immediately.

Upholstery:

- * To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.
- * Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.
- * Replace ripped or worn upholstery immediately.
- * Keep sharp or pointed objects clear of all upholstery.

Decals:

- * Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

Nuts and Bolts:

- * Inspect all nuts and bolts for any loosening and tighten if needed.
- * Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

Anti-Skid Surfaces:

- * These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

Belts and Cables:

- * We use only high quality belt, and mil-spec cables.
- * Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.
- * While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.
- * Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.

Belt and Cable Tension:

- * Referring to the Owners Manual, when belts or cables are used check all bolt attachments to be sure they are properly attached.
- * Check slack in cables and re-adjust cable tension if needed.

Seat Sleeves, Guide Rods:

- * Wipe down adjusting tubes with a dust free rag before applying lubricant.
- * Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

Linear Bearings:

- * Referring to the Owners Manual carefully disassemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. Repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

PLEASE KEEP THIS FOR YOUR RECORDS

Weight Training Tips

Use this manual to guide you through the basic exercises you can perform on your equipment. To gain maximum results and avoid possible injury, consult a fitness professional to develop your complete exercise program.

Always consult your physician before starting any exercise program.

To be successful in your exercise program, it is important to develop an understanding of the basic principles of strength training. Now that you have your equipment, it is only natural that you want to get started immediately. First, determine a set of realistic goals and objectives for yourself. By deciding on an exercise plan that is right for you prior to starting, you will contribute significantly to your success.

Warm up properly before engaging in weight resistance training. Stretching, yoga, jogging, calisthenics or other cardiovascular exercise can help prepare your body for the heavier workload of lifting weights.

Learn how to perform the exercise correctly before using heavy weight. Correct form is important to avoid injury and to ensure that you work the proper muscle groups.

Know your limitations. If you are new to weight training or are embarking on an exercise regimen after a long layoff, start slowly and build foundational strength over a longer period of time.

Pay attention to your breathing. Exhale when you exert is a general rule of thumb. Never hold your breath.

